



# S&W Race Cars and Components, Inc.

11 Mennonite Church Road  
Spring City, PA 19475

TECH & INFORMATION: 610-948-7303

ORDERS: 1-800-523-3353

OFFICE FAX: 610-948-7342

E-Z INFO FAX 610-792-1234

**CAUTION!!!** - The most important requirement for a successful installation of this, or any, S&W chassis component is that you take your time and use good common sense. Check & recheck all measurements before cutting or welding. If you have any questions, before or during the installation - STOP - and call our tech line at 610-948-7303 and we will gladly explain in more detail any step in the installation.

## Please read complete instructions thoroughly before beginning!

### Installation Instructions for 85-260 & 85-261 Battery Cable Kits

#### COMPRESSION TERMINALS:

- 1) Strip 7/8" of insulation from the end of your 1/0 cable.
- 2) Slip the shrink tubing over the wire.
- 3) Insert bared wire into the compression nut, supplied with the battery cable ends, until it is flush with or extended slightly past the compression nut.
- 4) Grip the compression nut with a wrench and turn the terminal until the compression nut seats.

#### HEAT SHRINK TUBING:

Heat shrinkable tubing seals terminals against corrosion.

- 1) Place the heat shrink tubing in place over the junction of the terminal and the cable.
- 2) Shrink the tubing with a heat gun.

#### PARTS LIST FOR PART# 85-260

QTY	PART#	DESCRIPTION
2	85-262	STRAIGHT CABLE END
4	85-264	3/8" STUD CABLE END
20'	85-267	1/0 BATTERY CABLE
2	85-265	3" RED SHRINK TUBING
4	85-266	3" BLACK SHRINK TUBING
2	99-006	S & W RACE CARS DECAL

#### PARTS LIST FOR PART# 85-261

QTY..	PART#	DESCRIPTION
2	85-262	STRAIGHT CABLE END
2	85-263	FLAG CABLE END
4	85-264	3/8" STUD CABLE END
20'	85-267	1/0 BATTERY CABLE
4	85-265	3" RED SHRINK TUBING
6	85-266	3" BLACK SHRINK TUBING
2	99-006	S & W RACE CARS DECAL