



**S&W Race Cars and  
Components, Inc.**  
11 Mennonite Church Road  
Spring City, PA 19475

TECH & INFORMATION: 610-948-7303

ORDERS: 1-800-523-3353

OFFICE FAX: 610-948-7342

***CAUTION!!! - The most important requirement for a successful installation of this, or any, S&W chassis component is that you take your time and use good common sense. Check & recheck all measurements before cutting or welding. If you have any questions, before or during the installation - STOP - and call our tech line at 610-948-7303 and we will gladly explain in more detail any step in the installation.***

**Please read complete instructions thoroughly before beginning!**

**Installation Instructions for 90-013 Tire Screw Template**

- 1. Template is for marking screw locations on 15" wheels, do not use as a drill guide.**
- 2. Center disk on wheel.**
- 3. Mark wheel at every slot for 16 screws or every other slot for 8 screws. Use a magic marker or sharpie type marker, the ink from these can be wiped off easily when you are done.**
- 4. Determine the edge of the screws. This distance will vary depending on the wheel manufacturer. Note; the head of the screw should not protrude past the edge of the wheel rim.**
- 5. Drill holes in wheel. Refer to the screw manufactures instructions for the drill size.**