

APPLY PRE LUBE
TO BOLTS

APPLY PRE LUBE
TO FACE OF BUSHING

APPLY PRE LUBE
ON MATING SURFACES

S & W RACE CARS
11 MENNONITE CHURCH RD
SPRING CITY, PA 19475

PRE-LUBE DIAGRAM

MAT'L:

PART No:

40-601 - 2